

## 3WF喷雾喷粉机 SPRAYER MIST-DUSTER



名称: 40多角启动器(TU43)  
40 STARTER  
NO:11007

名称: 40-3Z易拨盘(M10×1)  
40-3Z EASY PULLEY(M10×1)  
NO:2106

名称: 40易启动器B(一点红)  
EASY STARTER B  
NO:1818



喷粉机: 拨盘  
PULLEY  
NO:2105



喷粉机: 化油器  
CARBURETOR  
NO:3WF-003



喷粉机: 气缸  
CYLINDER  
NO:3WF-004



喷粉机: 火花塞  
SPARK PLUG  
NO:3WF-005



喷粉机: 活塞全套  
PISTON ASSY  
NO:3WF-006



喷粉机: 消声器  
MUFFLER  
NO:3WF-007



喷粉机: 风叶  
FAN BLADE  
NO:3WF-008



喷粉机: 曲轴  
CRANKSHAFT  
NO:3WF-009



喷粉机: 磁飞轮  
FLY WHEEL  
NO:3WF-010



喷粉机: 缸头盖铁垫  
STEEL GASKET  
(CYLINDER HEAD)  
NO:3WF-011



喷粉机: 冲压件  
STAMPING  
NO:3WF-012




喷粉机: 油门线/油门拉杆  
THROTTLE LINE  
THROTTLE LEVER  
NO:3WF-013



喷粉机: 油门组合  
THROTTLE ASSY  
NO:3WF-015



喷粉机: 销  
PIN  
NO:3WF-016



喷粉机: 橡胶垫  
RUBBER GASKET  
NO:3WF-017



喷粉机: 3WF-3点火线圈  
3WF-3 IGNITION COIL  
NO:FL074



喷粉机: 3WF-3高压包  
3WF-3 IGNITION COIL  
NO:FL075



喷粉机: 橡胶垫  
RUBBER PAD  
NO:3WF-018



喷粉机: 水阀销杆  
WATER VALVE PIN ROD  
NO:3WF-019



喷粉机: 橡胶垫  
RUBBER PAD  
NO:3WF-021



喷粉机: 弯管  
ELBOW  
NO:3WF-022



喷粉机: 水阀橡胶垫  
WATER VALVE  
RUBBER PAD  
NO:3WF-023



喷粉机: 风门销  
PIN(CHOKER ROD)  
NO:3WF-024



喷粉机: 弯管  
ELBOW  
NO:3WF-025



喷粉机: 背带  
BELT  
NO:3WF-026



喷粉机: 背架  
FRAME CARRIER  
NO:3WF-027



喷粉机: 靠背  
BACKBOARD  
NO:3WF-028



喷粉机: 提手架  
HANDLE BRACKET  
NO:3WF-029



喷粉机: 喷雾器喷头  
POWER SPRAY NOZLE  
NO:3WF-048



喷粉机: 空滤器  
AIR FILTER  
NO:3WF-020



喷粉机: 滚针轴承  
NEEDLE BEARING  
NO:3WF-031



喷粉机: 3WF-3减震脚  
ANTI-VIBRATION  
SUPPORT  
NO:3WF-032



喷粉机: 3WF-2.6减震脚  
ANTI-VIBRATION  
SUPPORT  
NO:3WF-032-1



喷粉机: 鼓风叶轮  
DRUM WIND IMPELLER  
NO:3WF-047



喷粉机: 连接座  
CONNECTING  
NO:3WF-033



喷粉机: 缸体罩  
CYLINDER COVER  
NO:3WF-034



喷粉机: 进气管  
INTAKE MANIFOLD  
NO:3WF-046



喷粉机: 网罩  
MESH ENCLOSURE  
NO:3WF-035



喷粉机: 风箱  
AIR BELLOW  
NO:3WF-036



喷粉机: 油壶盖  
FUEL TANK CAP  
NO:3WF-037



喷粉机: 药箱盖  
BARREL COVER  
NO:3WF-038



喷粉机: 药箱  
PESTICIDE CASE  
NO:3WF-039



喷粉机: 滤网  
STRAINER  
NO:3WF-040



喷粉机: 油滤网  
OIL STRAINER  
NO:3WF-041



喷粉机: 水管接  
PIPE JOINT  
NO:3WF-042



喷粉机: 3WF-2.6油箱  
FUEL TANK  
NO:3WF-043




喷粉机: 水阀座  
WATER VALVE SEAT  
NO:3WF-044



喷粉机: 下水管  
OUTFALL SEWER  
NO:3WF-045

## WFB-18 喷雾喷粉机 SPRAYEN MIST-DUSTER



喷粉机：右箱体  
RIGHT CASE  
NO:WFB-001



喷粉机：左箱体  
LEFT CASE  
NO:WFB-002



喷粉机：气缸  
CYLINDER  
NO:WFB-003



喷粉机：化油器  
CARBURETOR  
NO:WFB-004



喷粉机：点火器固定座  
IGNITION COIL SET  
NO:WFB-005



喷粉机：气缸盖  
CYLINDER COVER  
NO:WFB-006



喷粉机：火花塞  
SPARK PLUG  
NO:WFB-007



喷粉机：油箱开关  
FUEL TANK SWITCH  
NO:WFB-008



喷粉机：曲轴  
CRANKSHAFT  
NO:WFB-009



喷粉机：活塞全套  
PISTON ASSY  
NO:WFB-010



喷粉机：滚针轴承  
NEEDLE BEARING  
NO:WFB-011



喷粉机：风叶  
FAN BLADE  
NO:WFB-012



喷粉机：高压包  
IGNITION COIL  
NO:WFB-013



喷粉机：鼓风叶轮  
DRUM WIND IMPELLER  
NO:WFB-049




喷粉机：离合器  
CLUTCH  
NO:WFB-014



喷粉机：气缸铝垫  
CYLINDER GASKET(AL.)  
NO:WFB-015



喷粉机：桶盖密封垫圈  
SEAL WASHER  
NO:WFB-016



喷粉机：纸垫  
GASKET  
NO:WFB-017



喷粉机：喷雾器喷头  
POWER SPRAY NOZLE  
NO:WFB-048



喷粉机：磁飞轮  
FLY WHEEL  
NO:WFB-018



喷粉机：油门线  
THROTTLE LINE  
NO:WFB-047



喷粉机：弯管  
ELBOW  
NO:WFB-019



喷粉机：空滤器  
AIR FILTER  
NO:WFB-020



喷粉机：橡胶件  
RUBBER PARTS  
NO:WFB-021



喷粉机：油封  
OIL SEAL  
NO:WFB-022



喷粉机：鼓风机叶  
AIR BLOWER BLADE  
NO:WFB-023



喷粉机：进气管  
INTAKE MANIFOLD  
NO:WFB-046



喷粉机：减震支架  
ANTI-VIBRATION  
SUPPORT  
NO:WFB-024



喷粉机：消声器  
MUFFLER  
NO:WFB-025



喷粉机：背带  
BELT  
NO:WFB-026



喷粉机：背架  
FRAME CARRIER  
NO:WFB-027



喷粉机：靠背  
BACKBOARD  
NO:WFB-028



喷粉机：油门调节座  
THROTTLE  
ADJUSTER  
NO:WFB-029



喷粉机：油门支架  
THROTTLE  
SUPPORT  
NO:WFB-030



喷粉机：缸体罩  
CYLINDER COVER  
NO:WFB-031



喷粉机：风扇罩  
FAN COVER  
NO:WFB-032



喷粉机：启动器  
STARTER  
NO:WFB-033



喷粉机：药箱盖  
PESTICIDE  
BARREL COVER  
NO:WFB-034



喷粉机：药桶  
PESTICIDE BARREL  
NO:WFB-035



喷粉机：滤网  
STRAINER  
NO:WFB-036



喷粉机：油壶盖  
FUEL TANK CAP  
NO:WFB-037



喷粉机：油壶盖  
FUEL TANK  
NO:WFB-038



喷粉机：水阀总成  
WATER VALVE ASSY  
NO:WFB-039



喷粉机：下水接头  
WATER JOINT  
NO:WFB-040



喷粉机：出水管接  
OUTER JOINT  
NO:WFB-041



喷粉机：油滤网  
FUEL STRAINER  
NO:WFB-042



喷粉机：风箱  
AIR BELLOW  
NO:WFB-043



喷粉机：网罩  
MESH ENCLOSURE  
NO:WFB-044



喷粉机：调节阀  
ADJUSTER VALVE  
NO:WFB-045

## 3F-30喷粉机 SPRAYEN MIST-DUSTER



喷粉机：风箱左  
AIR BELLOW (LEFT)  
NO:3F30-001



喷粉机：风箱右  
AIR BELLOW(RIGHT)  
NO:3F30-002



喷粉机：箱体  
CYLINDER CASE  
NO:3F30-003



喷粉机：缸体罩  
CYLINDER COVER  
NO:3F30-004



喷粉机：调速座  
GOVERNOR SOCKET  
NO:3F30-005



喷粉机：水箱  
WATER TANK  
NO:3F30-006



喷粉机：背架  
FRAME CARRIER  
NO:3F30-007



喷粉机：启动器  
STARTER  
NO:3F30-008



喷粉机：气缸  
CYLINDER  
NO:3F30-009



喷粉机：火花塞  
SPARK PLUG  
NO:3F30-010



喷粉机：活塞总成  
PISTON ASSY.  
NO:3F30-011



喷粉机：曲轴  
CRANKSHAFT  
NO:3F30-012



喷粉机：磁飞轮  
FLYWHEEL  
NO:3F30-013



喷粉机：高压包  
IGNITION COIL  
NO:3F30-014



名称：3F-30化油器(TK)  
CARBURETOR  
NO:3F30-015-1



名称：3F-30化油器(瑞星)  
CARBURETOR  
NO:3F30-015-2



喷粉机：消声器  
MUFFLER  
NO:3F30-017



喷粉机：拨盘  
EASY PULLEY  
NO:3F30-016



喷粉机：阀门体  
VALVE  
NO:3F30-018



喷粉机：空滤器  
AIR FILTER  
NO:3F30-019



喷粉机：空滤器面板  
AIR FILTER COVER  
NO:3F30-020



喷粉机：塑料支架  
PLASTIC SUPPORT  
NO:3F30-021



喷粉机：水箱盖  
WATER COVER  
NO:3F30-022



喷粉机：风叶轮  
FAN WHEEL  
NO:3F30-023



喷粉机：隔板  
CLAPBOARD  
NO:3F30-024



喷粉机：出粉管  
DISCHARGE  
POWDER TUBE  
NO:3F30-025



喷粉机：0.6L配比壶  
0.6L MIXING BOTTLE  
NO:3F30-026



喷粉机：平衡器  
BALANCER  
NO:3F30-027



喷粉机：接头体  
CONNECTOR  
NO:3F30-028



喷粉机：水箱接口  
NO:3F30-029



喷粉机：油壶  
FUEL TANK  
NO:3F30-030



喷粉机：锁扣  
LOCK CATCH  
NO:3F30-031



喷粉机：出喷控制器  
CONTROLLER  
NO:3F30-032



喷粉机：不锈钢摇臂轴  
STAINLESS STEEL  
ROCKER ARM  
NO:3F30-033



喷粉机：锁圈  
RING  
NO:3F30-034



喷粉机：油管卡扣  
CLIP  
NO:3F30-035



喷粉机：垫片  
GASKET  
NO:3F30-036



喷粉机：滚针  
NEEDLE BEARING  
NO:3F30-037



喷粉机：油壶支架  
TANK SUPPORT  
NO:3F30-038



喷粉机：化油器隔热板  
HEAT INSULATOR BOARD  
(CARBURETOR)  
NO:3F30-039



喷粉机：消声器隔热板  
HEAT INSULATOR  
NO:3F30-040



喷粉机：支架压板  
SUPPORT PLATE  
NO:3F30-041



喷粉机：半圆键  
SEMI-KEY  
NO:3F30-042



喷粉机：进气管  
INTAKE MANIFOLD  
NO:3F30-043



喷粉机：盖板转轴  
SPINDLE  
NO:3F30-044



喷粉机：手把固定座  
FIXED SEAT  
NO:3F30-045



喷粉机：减震脚  
ANNULAR BUFFER  
NO:3F30-046




喷粉机：手把盖  
HANDLE COVER  
NO:3F30-047



喷粉机：减震脚  
ANTI-VIBRATION SUPPORT  
NO:3F30-048




B



A


喷粉机：进气管纸垫  
MANIFOLD GASKET  
NO:3F30-049




B



喷粉机：消声器纸垫  
MUFFLER GASKET  
NO:3F30-050



喷粉机：气缸纸垫  
CYLINDER GASKET  
NO:3F30-051



喷粉机：纸垫全套  
GASKET  
NO:3F30-085



喷粉机：空滤器密封垫  
SEALING GASKET  
NO:3F30-052



喷粉机：箱体纸垫  
GASKET  
NO:3F30-053



喷粉机：密封条  
SEALING  
NO:3F30-054



喷粉机：进气管纸垫  
GASKET  
NO:3F30-055

喷粉机：消声器垫  
GASKET  
NO:3F30-056



喷粉机：高压包盖  
IGNITION COIL  
COVER  
NO:3F30-057



喷粉机：减压阀  
REDUCING VALVE  
NO:3F30-058



喷粉机：海绵滤芯  
SPONGE (AIR FILTER)  
NO:3F30-059



喷粉机：羊毛垫滤芯  
SPONGE(WOOL MAT)  
NO:3F30-060



喷粉机：塑料网片  
PLASTIC MESHES  
NO:3F30-061



喷粉机：网片  
MESHES  
NO:3F30-061



喷粉机：弹簧  
SPRING  
NO:3F30-063



喷粉机：平垫  
GASKET  
NO:3F30-064



喷粉机：油管  
FUEL PIPE  
NO:3F30-065



喷粉机：平衡器管  
EQUALIZER PIPE  
NO:3F30-066



喷粉机：定位开关  
SWITCH  
NO:3F30-067



喷粉机：垫片  
GASKET  
NO:3F30-068



喷粉机：连接杆  
CONNECTING ROD  
NO:3F30-069



喷粉机：油门操作杆  
THROTTLE LEVER  
NO:3F30-070




喷粉机：粉门操作杆  
POWDER DOOR  
OPERATION LEVER  
NO:3F30-071



喷粉机：油门线  
THROTTLE CABLE  
NO:3F30-072



喷粉机：销杆  
PIN  
NO:3F30-073



喷粉机：防静电链条  
ANTI-STATIC CHAIN  
NO:3F30-074



喷粉机：白色出喷管  
PIPE (WHITE)  
NO:3F30-075



喷粉机：接头  
JOINT  
NO:3F30-076



NO:3F30-076



喷粉机：波纹出喷管  
TUBE  
NO:3F30-077



喷粉机：背带  
STRAPS  
NO:3F30-078



A

B



C

喷粉机：出喷管  
PIPE  
NO:3F30-079



喷粉机：大软管  
SOFT PIPE  
NO:3F30-080



喷粉机：短直管  
PIPE  
NO:3F30-081



喷粉机：长直管  
PIPE  
NO:3F30-082



喷粉机：长弯管  
ELBOW  
NO:3F30-083



喷粉机：喷口总成  
TUBE ASSY  
NO:3F30-084