

2冲程舷外机

2 STROKE OUTBOARD ENGINE

2.0P/2.6P/3.5P/4.0P/5.0P/6.0P/9.9P
15P/20P/25P/30P/35P/40P



TWO STROKE Model Item	Unit	T2BMS	T2.5BMS	T2.6BMS	T3.5BMS	T4BMS	T5BMS	T6BMS	T9.9BML	T9.9BMS	T13.5BML	T13.5BMS	T15BML	T15BMS	
Overall length	mm(in.)	550(21.6)	560(22.1)	605(23.8)	620(24.4)		700(27.6)		873(34.4)						
Overall width	mm(in.)	220(8.6)	220(8.6)	200(7.9)	220(8.6)		310(12.2)		330(13.0)						
Overall height	mm(in.)	920(36.2)	900(35.4)	945(37.2)	960(37.8)		1007(39.6)		1167(45.9)	1040(40.9)	1167(45.9)	1040(40.9)	1167(45.9)	1040(40.9)	
Transom height	mm(in.)		417(16.4)		432(17.0)		435(17.1)		567(22.3)	440(17.3)	567(22.3)	440(17.3)	567(22.3)	440(17.3)	
Weight	kg	8		10	17		20		37.5	36	37.5	36	37.5	36	
Full throttle operating range	r/min	4000-5500		3800-5200	4200-5300				4500-5500						
Maximum output	kw(HP)@r/min	1.4(2)@5000	1.8(2.5)@5000	1.9(2.6)@5000	2.5(3.5)@5000	2.9(4)@5000	3.6(5)@5000	4.4(6)@5000	7.3(9.9)@5000			9.9(13.5)@5000			11(15)@5000
Idling speed (in neutral)	r/min	1400-1500		1250-1350			1000-1100		700-800						
Engine type		2-Stroke													
Cylinders		1													
Displacement	cm ³	43	41	50	74.6		102		246						
Bore x stroke	mm(in.)	40x34(1.57x1.34)	40x32(1.57x1.26)	42x36(1.65x1.42)	47x43(1.85x1.69)		55x43(2.17x1.69)		56x50(2.20x1.97)						
Ignition system		TCI													
Control system		CDI													
Starting system		Tiller Manual													
Gear positions		\					Forward-neutral		Forward-neutral-reverse						
Gear ratio		2.08(27/13)					2.15(28/13)		2.08(27/13)						
Trim and tilt system		Manual tilt													
Integral fuel tank capacity	L	1.1	0.9	1.4	1.5		2.5		\						
Separate fuel tank capacity	L	\	\	\	\		12		24						
Maximum fuel waste	L/h	0.6	0.9	1.4	1.8	2.2	2.7	3.1	5.1			6.1		7.9	
Engine oil capacity (without oil filter)	L	Fuel/oil ratio 25:1					Fuel/oil ratio 50:1								
Gear oil capacity	cm ³	45					75		195						250
Propeller options*	in	3x7 1/4"x6"					3x7 1/4"x6"		3x7 4/5"x6"						3x9 1/4"x6"

* Propeller choice will vary by boat size and application.

2冲程舷外机 2 STROKE OUTBOARD ENGINE

2.0P/2.6P/3.5P/4.0P/5.0P/6.0P/9.9P
15P/20P/25P/30P/35P/40P



名称: 外罩
COVER
NO: XWJ2-001



名称: 箱体
CASE
NO: XWJ2-002



名称: 2556启动器 15P
2556 STARTER
NO: XWJ2-155



名称: 启动器
STARTER
NO: XWJ2-003



名称: 易启动器B(一点红)
EASY STARTER B
NO: 1818



名称: 易启动器
EASY STARTER
No: 2705



名称: 气缸盖
CYLINDER COVER
NO: XWJ2-004



名称: 磁飞轮
FLYWHEEL
NO: XWJ2-005



名称: 高压包
IGNITION COIL
NO: XWJ2-006



名称: 化油器
CARBURETOR
NO: XWJ2-007



名称: 火花塞
SPARK PLUG
NO: XWJ2-008



名称: 空滤器
AIR FLITER
NO: XWJ2-009



名称: 被动盘
CLUTH DRUM
NO: XWJ2-010



名称: 曲轴
CRANKSHAFT
NO: XWJ2-011



名称: 活塞
PISTON
NO: XWJ2-012



名称: 油封
OIL SEAL
NO: XWJ2-013



名称: 轴承
BEARING
NO: XWJ2-014



名称: 整流器
RECTIFIER
NO: XWJ2-015



名称: 传动轴保护套
DRIVE AXLE COVER
NO: XWJ2-016



名称: 滚针
NEEDLE
NO: XWJ2-017



名称: 熄火开关
STOP SWITCH
NO: XWJ2-018



名称: 整流器左右护套
RECTIFIER
SHEATH(L&R)
NO: XWJ2-019



名称: 进气阀簧片, 压板
INLET VALVE
SPRING, PLATE
NO: XWJ2-020



名称: 化油器纸垫
CARBURETOR
GASKET
NO: XWJ2-021



名称: 轴承挡圈
BEARING
RETAINER
NO: XWJ2-022



名称: 油壶减震器
FUEL TANK
DAMPER
NO: XWJ2-023



名称: 油壶防尘圈
FUEL TANK
DUST RING
NO: XWJ2-024



名称: 油壶
FUEL TANK
NO: XWJ2-025



名称: 油壶盖
FUEL TANK CAP
NO: XWJ2-026



名称: 触发器
TRIGGER
NO: XWJ2-027



名称: 点火线圈
IGNITION COIL
NO: XWJ2-028



名称: 托盘
PALLET
NO: XWJ2-029



名称: 螺旋桨
PROPELLER
NO: XWJ2-030



名称: 艉杆
STERN ROD
NO: XWJ2-031



名称: 操纵手柄
CONTROL HANDLE
NO: XWJ2-032



名称: 小转架
SMALL TURNER
NO: XWJ2-033



名称: 过滤器
FILTER
NO: XWJ2-034



名称: 传动小齿轮
PINION
NO: XWJ2-035



名称: 机油泵总成
OIL PUMP ASSY
NO: XWJ2-036



名称: 右支架
R. SUPPORT
NO: XWJ2-037



名称: 左支架
L. SUPPORT
NO: XWJ2-038



名称: 星形内齿轮
STAR GEAR, INNER
NO: XWJ2-039



名称: 星形外齿轮
STAR GEAR, OUT
NO: XWJ2-040



名称: 换挡手柄
SHIFT HANDLE
NO: XWJ2-041



名称: 齿轮箱
GEAR CASE
NO: XWJ2-042



名称: 自吸泵
SELF-SUCTION
PUMP
NO: XWJ2-043



名称: 熄火开关
STOP SWITCH
NO: XWJ2-044



名称: 指示灯
PILOT LAMP
NO: XWJ2-045



名称: 传动轴保护套
SHAFT BRACER
NO: XWJ2-046



名称: 汽油过滤器
FILTER
NO: XWJ2-047



名称: 花键轴
SPLINE SHAFT
NO: XWJ2-048



名称: 排水阀盖
DRAIN VALVE COVER
NO: XWJ2-049


名称: 齿轮箱盖
GEAR CASE COVER
NO: XWJ2-050

名称: 水泵下盖
BOTTOM COVER
NO: XWJ2-051

名称: 水泵上盖
UP COVER
NO: XWJ2-052

名称: 离合齿
CLUTCH TOOTH
NO: XWJ2-053

名称: 前进齿
FORWARD TOOTH
NO: XWJ2-054



名称: 倒齿
REVERSE TOOTH
NO: XWJ2-055

名称: 进气管
INTAKE MANIFOLD
NO: XWJ2-056

名称: 大转架
BIG TURNER
NO: XWJ2-057

名称: 机油泵盖
OIL PUMP COVER
NO: XWJ2-058

名称: 气门油封
OIL SEAL OF VALVE
NO: XWJ2-059

名称: 合罩手柄减磨垫
WASHER
NO: XWJ2-060



名称: 黄油嘴
GREASE FITTING
NO: XWJ2-061

名称: 油门转把
ROTARY HANDLE
NO: XWJ2-062

名称: 操纵手柄密封圈
SEAL RING OF HANDLE
NO: XWJ2-063

名称: 三通
THREE LINKS
NO: XWJ2-064

名称: 转架锁紧螺母
NUT
NO: XWJ2-065

名称: 自锁拉杆护套
PROTECT ROD
NO: XWJ2-066



名称: 压紧盘
COMPACT DISC
NO: XWJ2-067

名称: 螺旋桨垫块
PROPELLER SPACER BLOCK
NO: XWJ2-068

名称: 小密封盖
SEAL CAP, SMALL
NO: XWJ2-069

名称: 油箱支架减震套
DAMPER
NO: XWJ2-070

名称: 进水管密封圈
INLET SEAL RING
NO: XWJ2-071

名称: 油封25X40X8
OIL SEAL
NO: XWJ2-072



名称: 转杆调节手柄
ADJUSTER HANDLE
NO: XWJ2-073


名称: 机油滤总成
OIL FILTER ASSY.
NO: XWJ2-074

名称: 油门线下座
THROTTLE LEVER SEAT
NO: XWJ2-075

名称: 油门线上座
PLATE OF THROTTLE LEVER LINE
NO: XWJ2-076

名称: 油门线
THROTTLE LEVER LINE
NO: XWJ2-077

名称: 齿轮箱盖O型圈
O-RING, GEAR BOX
NO: XWJ2-078



名称: 机油管夹
OIL PIPE CLIP
NO: XWJ2-079

名称: 油管
OIL PIPE
NO: XWJ2-080

内径: 5MM
外径: 10MM

INNER DIAMETER: 5MM
OUTER DIAMETER: 10MM



名称: 油管
OIL PIPE
NO: XWJ2-081

名称: 波纹管
RIBBED TUBE
NO: XWJ2-082

名称: 小减震圈
DAMPER, SMALL
NO: XWJ2-083

名称: 大减震圈
DAMPER, BIG
NO: XWJ2-084



名称: 机油压力传感器
OIL SENSOR
NO: XWJ2-085

名称: 合罩手柄
HANDLE
NO: XWJ2-086

名称: 上倾锁定臂
LOCKING ARM
NO: XWJ2-087

名称: 转架轴瓦
ROTATING FRAME BEARING
NO: XWJ2-088

名称: 油门转杆
THROTTLE LEVER
NO: XWJ2-089

名称: 钳子手柄
THE CLAMP HANDLE
NO: XWJ2-090



名称: 油壶支架
SUPPORT OF FUEL TANK
NO: XWJ2-091

名称: 调节口盖
REGULATOR COVER
NO: XWJ2-092

名称: 锁定臂轴瓦
LOCKING ARM BEARING
NO: XWJ2-093

名称: 管夹
PIPE CLIP
NO: XWJ2-094

名称: 线夹
CLIP
NO: XWJ2-095

名称: 转杆调节器
THE ROTATING ROD ADJUSTER
NO: XWJ2-096



名称: 倾斜销弹簧
TOWER SPRING
NO: XWJ2-097

名称: 倾斜锁勾
TILT LOCK HOOK
NO: XWJ2-098

名称: 机油管密封套
SEAL OF OIL PIPE
NO: XWJ2-099

名称: 滚针衬套
SLEEVE OF NEEDLE BEARING
NO: XWJ2-100

名称: 调整上下压块
ADJUST PRESSING BLOCKS
NO: XWJ2-101

名称: 换挡拉杆密封座
GEAR CHANGE ROD SEAL SEAT
NO: XWJ2-102

USK 优斯凯进出口 TRADE



名称: 大密封圈
BIG SEAL CAP
NO: XWJ2-103



名称: 转架锁紧压簧
LOCKING SPRING
NO: XWJ2-104



名称: 变档弹簧
GEAR SPRING
NO: XWJ2-105



名称: 通气室密封垫
VENTILATION
ROOM GASKET
NO: XWJ2-106



名称: 通气室盖板
PLATE, VENTILATION
ROOM
NO: XWJ2-107



名称: 合罩手柄爪
COMBINED COVER
HANDLE CLAW
NO: XWJ2-108



名称: 锁定臂压板
LOCKING ARM PLATE
NO: XWJ2-109



名称: 夹紧螺栓
BOLT
NO: XWJ2-110



名称: 机油压力传感器
OIL PRESSURE
SENSOR
NO: XWJ2-111



名称: 进油接头护套
OIL INLET JOINT
COVER
NO: XWJ2-112



名称: 锁勾左扭簧
TORSIONAL SPRING
NO: XWJ2-113



名称: 变档摆架
GEARSHIFT
SWINGING RACK
NO: XWJ2-114



名称: O型圈
O-RING
NO: XWJ2-115



名称: 油封
OIL SEAL
NO: XWJ2-116



名称: 转架上密封圈
OIL SEAL
NO: XWJ2-117



名称: 导向弹簧
GUIDE SPRING
NO: XWJ2-118



名称: 操纵手柄压板
PLATE OF
CONTROL HANDLE
NO: XWJ2-119



名称: 锁定臂弹簧
LOCKING ARM
SPRING
NO: XWJ2-120



名称: 隔水板
WATER-STOP
SHEET
NO: XWJ2-121



名称: 操纵手柄密封垫圈
HANDLE SEALING
WASHER
NO: XWJ2-122



名称: 通气管
BREATHER PIPE
NO: XWJ2-123



名称: 密封压板
SEAL PLATE
NO: XWJ2-124



名称: 操纵手柄密封垫圈
HANDLE SEALING
WASHER
NO: XWJ2-125



名称: 机油管夹
OIL PIPE CLIP
NO: XWJ2-126



名称: 转向挺柱
REVERSING
TAPPET
NO: XWJ2-127



名称: 螺旋桨挡片
PROPELLER
GUARD SHEET
NO: XWJ2-128



名称: 传动轴保护套
DRIVE SHAFT
PROTECTIVE SLEEVE
NO: XWJ2-129



名称: 托架连接片
THE BRACKET
CONNECTING PIECE
NO: XWJ2-130



名称: 柱塞
PLUGER
NO: XWJ2-131




名称: 机油管
OIL PIPE
NO: XWJ2-132

USK 优斯凯进出口 TRADE



名称: 隔热垫
RISER PAD
NO: XWJ2-133



名称: 螺丝/螺母
SCREW/NUT
NO: XWJ2-134



M12(1.25)



M10(1.25)



M10X12(1.25)

名称: 变档拉杆
SHIFT ROD
NO: XWJ2-135

名称: 摆架拉杆
SWING FRAME ROD
NO: XWJ2-136

名称: 倾斜销
ANGULAR PIN
NO: XWJ2-137

名称: 自锁拉杆
SELF-LOCKING ROD
NO: XWJ2-138

名称: 水泵出水管
DISCHARGE PUMP
NO: XWJ2-139



名称: 风门线
THROTTLE LINE
NO: XWJ2-140



名称: 推杆
PUSH ROD
NO: XWJ2-141




名称: 传动轴
DRIVESHAFT
NO: XWJ2-142




名称: 缸头罩密封垫
CYLINDER HEAD
GASKET
NO: XWJ2-143




名称: 气缸垫片
CYLINDER GASKET
NO: XWJ2-144



名称: 6HP
1E55气缸垫
CYLINDER
GASKET
NO: XWJ2-145



名称: 3.5HP
1E47气缸垫
CYLINDER
GASKET
NO: XWJ2-146



名称: 4冲 15HP
259气缸垫
CYLINDER
GASKET
NO: XWJ2-147



名称: 2冲 15HP
2E56气缸垫
CYLINDER
GASKET
NO: XWJ2-148



名称: 油箱盖
OIL CAP
NO: XWJ2-149



名称: 油箱感应器垫片
PLASTIC FUEL TANK
SENSOR GASKET
NO: XWJ2-150



名称: 12L油箱
12L PLASTIC
FUEL TANK
NO: XWJ2-151



名称: 24L油箱
24L PLASTIC
FUEL TANK
NO: XWJ2-152



名称: 油箱感应器总成
PLASTIC FUEL TANK
SENSOR ASSY
NO: XWJ2-153



名称: 熄火开关配件
FLAMEOUT SWITCH
ACCESSORIES
NO: XWJ2-154

4冲程舷外机

4 STROKE OUTBOARD ENGINE

2.5P/4.0P/5.0P/6.0P/9.9P/15P202530



FOUR STROKE	Model Item	Unit	F2.5BMS	F4BMS	F5BMS	F6BMS	F9.9BML	F9.9BMS	F13.5BML	F13.5BMS	F15BML	F15BMS
Overall length	mm(in.)	623(25.4)			680(26.8)							1001(39.4)
Overall width	mm(in.)	345(13.6)			325(12.8)							427(16.8)
Overall height	mm(in.)	1021(40.2)			1073(42.2)		1080(42.5)	953(37.5)	1080(42.5)	953(37.5)	1080(42.5)	953(37.5)
Transom height	mm(in.)	432(17.0)			435(17.1)		567(22.3)	440(17.3)	567(22.3)	440(17.3)	567(22.3)	440(17.3)
Weight	kg	17			26		47	44	47	44	47	44
Full throttle operating range	r/min	5250-5750	4500-5500		5000-6000							4500-5500
Maximum output	kw(HP)@r/min	1.8(2.5)@5500	2.9(4)@5000		3.7(5)@5500	4.4(6)@5500		7.3(9.9)@5000		9.9(13.5)@5000		11(15)@5000
Idling speed (in neutral)	r/min	1800-2000			1500-1600							900-1000
Engine type					OHV							OHC
Cylinders					1							
Displacement	cm ³	72			123							
Bore x stroke	mm(in.)	54x31.5(2.13x1.24)			59x45(2.32x1.77)							
Ignition system					TCI							
Control system												Tiller
Starting system												Manual
Gear positions		Forward-neutral										Forward-neutral-reverse
Gear ratio		2.08(27/13)			2.15(28/13)							2.08(27/13)
Trim and tilt system												Manual tilt
Integral fuel tank capacity	L	1			1.1							1
Separate fuel tank capacity	L	\			12							24
Maximum fuel waste	L/h	1.1	1.6		2	2.4		3.5		4.8		5.3
Engine oil capacity (without oil filter)	L	0.35			0.45							1
Gear oil capacity	cm ³	75			195							250
Propeller options*	in	3x7 1/4"x6"			3x7 4/5"x8"							3x9 1/4"x11"

* Propeller choice will vary by boat size and application.

4冲程舷外机 4 STROKE OUTBOARD ENGINE 2.5P/4.0P/5.0P/6.0P/9.9P/15P



名称: 外罩
COVER
NO: XWJ4-001

名称: 气缸体
CYLINDER
NO: XWJ4-002

名称: 箱体
CYLINDER CASE
NO: XWJ4-003

名称: 259S启动器 15P
259S STARTER
NO: XWJ4-160



名称: 雅马哈启动器
STARTER 3P
NO: XWJ4-161

名称: 雅马哈启动器
STARTER 5P
NO: XWJ4-162

名称: 启动器
STARTER
NO: XWJ4-004

名称: 空滤器
AIR FILTER
NO: XWJ4-005

名称: 凸轮轴
CAMSHAFT
NO: XWJ4-006

名称: 化油器
CARBURETOR
NO: XWJ4-007

名称: 活塞
PISTON
NO: XWJ4-008



名称: 排水阀盖
DRAIN VALVE
COVER
NO: XWJ4-009

名称: 磁飞轮
FLYWHEEL
NO: XWJ4-010

名称: 高压包
IGNITION COIL
NO: XWJ4-011

名称: 托盘
PALLET
NO: XWJ4-012

名称: 曲轴
CRANKSHAFT
NO: XWJ4-013

名称: 连杆
CONNECTING ROD
NO: XWJ4-014

名称: 火花塞
SPARK PLUG
NO: XWJ4-015



名称: 螺旋桨
PRO PELLER
NO: XWJ4-016

名称: 箱体
CYLINDER CASE
NO: XWJ4-017

名称: 油开关
OIL SEITCH
NO: XWJ4-018

名称: 舵杆
STERN ROD
NO: XWJ4-019

名称: 操纵手把
CONTROL HANDLE
NO: XWJ4-020

名称: 小转架
SMALL TURNER
NO: XWJ4-021



名称: 过滤器
FILTER
NO: XWJ4-022


名称: 传动小齿轮
PINION
NO: XWJ4-023

名称: 机油泵总成
OIL PUMP ASSY
NO: XWJ4-024

名称: 齿轮箱盖
GEAR CASE COVER
NO: XWJ4-025

名称: 水泵下盖
BOTTOM COVER
NO: XWJ4-026

名称: 水泵上盖
UP COVER
NO: XWJ4-027



名称: 右支架
R. SUPPORT
NO: XWJ4-028

名称: 左支架
L. SUPPORT
NO: XWJ4-029

名称: 星形内齿轮
STAR GEAR, INNER
NO: XWJ4-030

名称: 星形外齿轮
STAR GEAR, OUT
NO: XWJ4-031

名称: 换挡手柄
SHIFT HANDLE
NO: XWJ4-032

名称: 齿轮箱
GEAR CASE
NO: XWJ4-033



名称: 自吸泵
SELF-SUCTION
PUMP
NO: XWJ4-034

名称: 熄火开关
STOP SWITCH
NO: XWJ4-035

名称: 指示灯
PILOT LAMP
NO: XWJ4-036

名称: 传动轴保护套
SHAFT BRACER
NO: XWJ4-037

名称: 汽油过滤器
FILTER
NO: XWJ4-038

名称: 花键轴
SPLINE SHAFT
NO: XWJ4-039



名称: 离合齿
CLUTCH TOOTH
NO: XWJ4-040

名称: 前进齿
FORWARD
TOOTH
NO: XWJ4-041

名称: 倒齿
REVERSE
TOOTH
NO: XWJ4-042

名称: 进气管
INTAKE MANIFOLD
NO: XWJ4-043

名称: 6205轴承
6205 BEARING
NO: XWJ4-044

名称: 大转架
BIG TURNER
NO: XWJ4-045



名称: 并紧螺母
LOCK NUT
NO: XWJ4-046

名称: 球头螺母
BALL NUT
NO: XWJ4-047

名称: 挺柱
TAPPET
NO: XWJ4-048

名称: 摇臂
ROCKER
ARM ASSY.
NO: XWJ4-049

名称: 外置油箱插座
SOCKET
NO: XWJ4-050

名称: 油封20X35X7
OIL SEAL
NO: XWJ4-051



名称: 缸头罩
CASE COVER
NO: XWJ4-052

名称: 机油泵盖
OIL PUMP COVER
NO: XWJ4-053

名称: 气门油封
OIL SEAL OF VALVE
NO: XWJ4-054

名称: 合罩手柄减磨垫
WASHER
NO: XWJ4-055

名称: 黄油嘴
GREASE FITTING
NO: XWJ4-056

名称: 转把
ROTARY HANDLE
NO: XWJ4-057



名称: 操纵手柄密封圈
SEAL RING OF
HANDLE
NO: XWJ4-058

名称: 油壶盖
FUEL TANK CAP
NO: XWJ4-059

名称: 油壶
FUEL TANK
NO: XWJ4-060

名称: 三通
THREE LINKS
NO: XWJ4-061

名称: 进排气门
INLET/OUTLET
VALVE
NO: XWJ4-062

名称: 转架锁紧螺母
NUT
NO: XWJ4-063



名称: 压紧盘
COMPACT DISC
NO: XWJ4-064

名称: 螺旋桨垫块
PROPELLER SPACER
BLOCK
NO: XWJ4-065

名称: 小密封盖
SEAL CAP, SMALL
NO: XWJ4-066

名称: 油箱支架减震套
DAMPER
NO: XWJ4-067

名称: 进水管密封圈
INLET SEAL RING
NO: XWJ4-068

名称: 油封25X40X8
OIL SEAL
NO: XWJ4-069



名称: 自锁拉杆护套
PROTECT ROD
NO: XWJ4-070

名称: 机油压力传感器
OIL SENSOR
NO: XWJ4-071

名称: 转杆调节器
THE ROTATING
ROD ADJUSTER
NO: XWJ4-072

名称: 风门手把密封套
SEAL OF DOOR
HANDLE
NO: XWJ4-073

名称: 机油管密封套
SEAL OF OIL PIPE
NO: XWJ4-074

名称: 风门手柄
DOOR HANDLE
NO: XWJ4-075



名称: 转杆调节手柄
ADJUSTER HANDLE
NO: XWJ4-076

名称: 机油滤总成
OIL FILTER ASSY.
NO: XWJ4-077


名称: 油门线下座
THROTTLE
LEVER SEAT
NO: XWJ4-078

名称: 油门线上座
PLATE OF THROTTLE
LEVER LINE
NO: XWJ4-079

名称: 油门线
THROTTLE
LEVER LINE
NO: XWJ4-080

名称: 行程: 9CM
STROKE: 9CM

名称: 齿轮箱盖O型圈
O-RING, GEAR BOX
NO: XWJ4-081



名称: 机油管夹
OIL PIPE CLIP
NO: XWJ4-082

名称: 油管
OIL PIPE
NO: XWJ4-083

内径: 5MM
外径: 10MM

INNER DIAMETER: 5MM
OUTER DIAMETER: 10MM



名称: 油管
OIL PIPE
NO: XWJ4-083

名称: 螺纹管
RIBBED TUBE
NO: XWJ4-084

名称: 小减震圈
DAMPER, SMALL
NO: XWJ4-085

名称: 大减震圈
DAMPER, BIG
NO: XWJ4-086



名称: 机油尺
OIL DIPSTICK
NO: XWJ4-087

名称: 合罩手柄
HANDLE
NO: XWJ4-088

名称: 上倾锁定臂
LOCKING ARM
NO: XWJ4-089

名称: 转架轴瓦
ROTATING
FRAME BEARING
NO: XWJ4-090

名称: 油门转杆
THROTTLE LEVER
NO: XWJ4-091

名称: 钳位手柄
THE CLAMP HANDLE
NO: XWJ4-092



名称: 油壶支架
SUPPORT OF
FUEL TANK
NO: XWJ4-093

名称: 调节口盖
REGULATOR
COVER
NO: XWJ4-094

名称: 锁定臂轴瓦
LOCKING ARM
BEARING
NO: XWJ4-095

名称: 管夹
PIPE CLIP
NO: XWJ4-096

名称: 线夹
CLIP
NO: XWJ4-097

名称: 气门弹簧座
SPRING
SEAT, VALVE
NO: XWJ4-098



名称: 倾斜销弹簧
TOWER SPRING
NO: XWJ4-099

名称: 倾斜锁勾
TILT LOCK HOOK
NO: XWJ4-100

名称: 气门锁夹
VALVE LOCK CLAMP
NO: XWJ4-101

名称: 滚针衬套
SLEEVE OF
NEEDLE BEARING
NO: XWJ4-102

名称: 调整上下压块
ADJUST
PRESSING BLOCKS
NO: XWJ4-103

名称: 变档拉杆密封座
GEAR CHANGE ROD
SEAL SEAT
NO: XWJ4-104



名称: 气门弹簧
VALVE SPRING
NO: XWJ4-105



名称: 转架锁紧压簧
LOCKING SPRING
NO: XWJ4-106



名称: 变档弹簧
GEAR SPRING
NO: XWJ4-107



名称: 通气室密封垫
VENTILATION
ROOM GASKET
NO: XWJ4-108



名称: 通气室盖板
PLATE, VENTILATION
ROOM
NO: XWJ4-109



名称: 合罩手柄爪
COMBINED COVER
HANDLE CLAW
NO: XWJ4-110



名称: 锁定臂压板
LOCKING ARM PLATE
NO: XWJ4-111



名称: 夹紧螺栓
BOLT
NO: XWJ4-112



名称: 机油压力传感器
OIL PRESSURE
SENSOR
NO: XWJ4-113



名称: 进油接头护套
OIL INLET JOINT
COVER
NO: XWJ4-114



名称: 锁勾左扭簧
TORSIONAL SPRING
NO: XWJ4-115



名称: 变档摆架
GEARSHIFT
SWINGING RACK
NO: XWJ4-116



名称: O型圈
O-RING
NO: XWJ4-117



名称: 油封
OIL SEAL
NO: XWJ4-118



名称: 转架上密封圈
OIL SEAL
NO: XWJ4-119



名称: 导向弹簧
GUIDE SPRING
NO: XWJ4-120



名称: 风门拉杆
CHOKER ROD
NO: XWJ4-121



名称: 锁定臂弹簧
LOCKING ARM
SPRING
NO: XWJ4-122



名称: 隔水板
WATER-STOP
SHEET
NO: XWJ4-123



名称: 操纵手柄密封垫圈
HANDLE SEALING
WASHER
NO: XWJ4-124



名称: 通气管
BREATHER PIPE
NO: XWJ4-125



名称: 密封压板
SEAL PLATE
NO: XWJ4-126



名称: 操纵手柄密封垫圈
HANDLE SEALING
WASHER
NO: XWJ4-127



名称: 机油管夹
OIL PIPE CLIP
NO: XWJ4-128



名称: 转向挺柱
REVERSING
TAPPET
NO: XWJ4-129



名称: 螺旋桨挡片
PROPELLER
GUARD SHEET
NO: XWJ4-130



名称: 传动轴保护套
DRIVE SHAFT
PROTECTIVE SLEEVE
NO: XWJ4-131



名称: 托架连接片
THE BRACKET
CONNECTING PIECE
NO: XWJ4-132



名称: 柱塞
PLUGGER
NO: XWJ4-133



名称: 机油管
OIL PIPE
NO: XWJ4-134



名称: 操纵手柄压板
PLATE OF
CONTROL HANDLE
NO: XWJ4-135



名称: 隔热垫
RISER PAD
NO: XWJ4-136



名称: 半圆键
WOODRUFF KEY
NO: XWJ4-137



名称: 滚珠
BALL
NO: XWJ4-138



名称: 变档拉杆
SHIFT ROD
NO: XWJ4-139



名称: 摆架拉杆
SWING FRAME ROD
NO: XWJ4-140



名称: 倾斜销
ANGULAR PIN
NO: XWJ4-141



名称: 自锁拉杆
SELF-LOCKING ROD
NO: XWJ4-142



名称: 水泵出水管
DISCHARGE PUMP
NO: XWJ4-143



名称: 风门线
THROTTLE LINE
NO: XWJ4-144



名称: 推杆
PUSH ROD
NO: XWJ4-145



名称: 传动轴
DRIVESHAFT
NO: XWJ4-146



名称: 螺丝/螺母
SCREW/NUT
NO: XWJ4-147



M12(1.25) M10(1.25) M10X12(1.25)




名称: 缸头罩密封垫
CYLINDER HEAD
GASKET
NO: XWJ4-148




名称: 气缸垫片
CYLINDER GASKET 149001




名称: 6HP
1E55气缸垫
CYLINDER
GASKET
NO: XWJ4-150



名称: 3.5HP
1E47气缸垫
CYLINDER
GASKET
NO: XWJ4-151



名称: 4冲 15HP
259气缸垫
CYLINDER
GASKET
NO: XWJ4-152



名称: 2冲 15HP
2E56气缸垫
CYLINDER
GASKET
NO: XWJ4-153



名称: 油箱盖
OIL CAP
NO: XWJ4-154



名称: 油箱感应器垫片
PLASTIC FUEL LANK
SENOR GASKET
NO: XWJ4-155



名称: 12L油箱
12L PLASTIC
FUEL TANK
NO: XWJ2-151



名称: 24L油箱
24L PLASTIC
FUEL TANK
NO: XWJ2-152



名称: 油箱感应器总成
PLASTIC FUEL LANK
SENOR ASSY
NO: XWJ4-158



名称: 熄火开关配件
FLAMEOUT SWITCH
ACCESSORIES
NO: XWJ4-159

2冲程舷外机

2 STROKE OUTBOARD ENGINE

2.5P/4.0P/5.0P/6.0P/9.9P/15P

